


ZOOM H2 Simple Recording Guide

1 Turn power to H2 on





Set [POWER] switch ON.

2 Press (REC) key to set H2 to recording mode



[PLAY/REC] indicator flashes red.

3 Adjust sensitivity with [MIC GAIN] switch



You can monitor the input level.

4 Press (REC) key once more to start recording



Now stays constantly lit red.

5 Press (REC) key to stop recording




Unit returns to the start of the recorded file.

6 Press (PLAY/PAUSE) key to play the recorded file



[PLAY/REC] indicator lites green.



Tips for Mic pattern setting


Switching mic pattern by object or situation is effective for your recording.



FRONT 90




For recording solo vocal or a musical instrument.




REAR 120



For stereo recording widely with room ambience.



SURROUND



For recording band rehearsal etc. It is possible to pick up the sound from front and rear side of H2 at once.

Use windscreen on mic of H2 when outdoor recording.



It can reduce wind hitting noise.

Rec Guide-E-2

Entire Manual Available at: <http://www.lib.jmu.edu/media/EquipmentManuals>

Tips for general speech recording of excellent quality and long recording time:

Select MENU, then change these settings

- Rec mode = MP3 192kbps
- Mono Mix = ON
- AGC/Comp = ON
- Monitor = ON (allows you to check the audio level before or while recording)
- Mic: Surround 2 Ch (uses front and back mics, mixing sound to one channel.)